

ISI Housing Installation Instructions



Using the two screws provided, mount the ISI Housing vertically on the end panel of your choosing or horizontally under the worksurface of the unit. The ISI should be located where it will be most easily accessible without interfering with the daily usage of your unit.